



**PART#: DXMC-1 California Mirror
INSTALLATION INSTRUCTIONS**



1. Remove OEM mirrors.
2. Verify that the perch stem is 10mm. Use the 10 x 1.25 right hand threaded bolt and install mirror into OEM mirror mounting perch.
3. Repeat step #2 on the left side mirror.
4. Adjust mirrors to desired position and tighten using blue Loctight.

DXMC-1 California Mirror Tools Needed	
1) M8 Allen Key	2) Blue Loctight

THIS PRODUCT IS INTENDED TO BE INSTALLED BY A CERTIFIED TECHNICIAN*



**PART#: DXMC-1 California Mirror
INSTALLATION INSTRUCTIONS**



1. Remove OEM mirrors.
2. Verify that the perch stem is 10mm. Use the 10 x 1.25 right hand threaded bolt and install mirror into OEM mirror mounting perch.
3. Repeat step #2 on the left side mirror.
4. Adjust mirrors to desired position and tighten using blue Loctight.

DXMC-1 California Mirror Tools Needed	
1) M8 Allen Key	2) Blue Loctight

THIS PRODUCT IS INTENDED TO BE INSTALLED BY A CERTIFIED TECHNICIAN*