



www.GRAVESPORT.com

Toll Free: 800-867-6480 Fax: 818-902-3821

7629 Densmore Avenue
Van Nuys, Ca. 91406

AB016

BMW Smog Block-Off Plates BMW S1000RR 2010-2014

PARTS LIST

- Smog Block Off Plates 2
- Airbox Cap 1



<<<<< IT IS RECOMMENDED THAT THIS PRODUCT BE INSTALLED BY A QUALIFIED TECHNICIAN >>>>>

- 1) Make sure the bike is off and has had time for the motor and components to completely cool off.
- 2) Carefully remove the fairings, fuel tank and air box.
- 3) Use a short 5mm Allen wrench to remove the bolts from the smog port covers. The bolts have loctite and will be very tight.
- 4) Apply blue loctite to the stock bolts and install the smog block off plates.
- 5) Remove the air hose leading from the airbox to the smog port and cover the outlet with the included cap. Be sure to secure the cap with a zip tie or safety wire.
- 6) Reinstall the airbox, fuel tank, and fairings.



More Graves Parts for your BMW



FEB-10S1RR-K
BMW Fender Eliminator Kit



EXB-14S1RR-SOT
BMW Slip-On

See more at:
www.GRAVESPORT.com

The purchaser releases Graves Motorsports, Inc from all liabilities pertaining to the installation and use of purchased parts. Purchaser recognizes that any alteration and/or modifications to the vehicle may increase the risk of injury or accident. **This product is intended for Closed Course Competition Use Only** and may render the vehicle illegal for use on public roads.