



## AB014: Smog Block-Off Plate

## HONDA CBR250R 2011-2013

### PARTS LIST

- Smog Block-Off Plate 1
- Airbox Cap 1

<<<<<< IT IS RECOMMENDED THAT THIS PRODUCT BE INSTALLED BY A QUALIFIED TECHNICIAN >>>>>>

- 1) Remove the fuel tank.

Under the rubber heat shield, locate the smog pump and valve cover with the stock smog plate attached.

- 2) Remove the stock smog plate, smog pump and all of the accompanying hoses.

- 3) Replace the stock smog plate that was located on the valve cover with the **Graves Smog Block-Off Plate (Photo 1)**.

**Do not remove the reed cage that is located below the smog plate.**



Photo 1

- 4) Cover the nipple on the air box, where the smog pump hose was connected, with the rubber **Airbox Cap** provided. Secure with the stock clamp or zip tie. **(Photo 2)**.



Photo 2

- 5) Reinstall the fuel tank.