

CUSTOM MOTORCYCLE ACCESSORIES

# NEW RAGE CYCLES

## DUCATI 1199 / 899 PANIGALE

### FRONT TURN SIGNALS

1. Remove two 4mm allen bolts (picture 1)
2. Unplug stock connector (picture 2)
3. Slide bolts through block off and into front fairing, plugging in new turn signal (picture 3)
4. With a pair of pliers, slide connector and wiring back into fairing
5. Slide new bolt through block off plate and tighten nut on back side (picture 4)



To inquire about custom parts installations

**CONTACT US**

**INFO@NEWRAGECYCLES.COM | 914.339.2929**