

NEW RAGE CYCLES

INSTALLATION INSTRUCTIONS

BMW S1000RR

FRONT TURN SIGNALS

- 1 With T30 torx, unbolt stock signal from fairing (picture 1)
- 2 Remove stock signal lenses with Philips head screw driver (picture 2)
- 3 Slide housing out and disconnect spade connectors, leaving wiring harness in place (picture 3)
- 4 Make your connections as follows, then shrink tube connections: (picture 4)
 - LH signal: Blue/Red Tracer NRC Red wire
 - LH Signal: Brown NRC Black wire
 - RH Signal: Blue/Red Tracer NRC Red wire
 - RH Signal: Brown NRC Black Wire
- 5 Feed wires in bike and bolt on new turn signal using stock bolt (picture 5)

