



401 South Grand Ave., Santa Ana, CA 92705
Tel: 714.550.6070 Fax: 714.550.9661 www.twobros.com

Kawasaki
NINJA 300
Full Exhaust System
Part # 005-3890105-T

TARMAC




Installation Instructions

1. Make sure the bike is completely cool before starting the installation. Make sure the bike is secure on a centerstand or ideally a service lift.
2. Remove bottom fairings by removing six bolts. (3 each side)



3. Remove the OEM muffler assembly.



4. Remove OEM header and take off header gaskets for use with TBR header.



5. Remove clip and pin from passenger foot peg, replace with 6x45mm bolt.




6. Install Muffler bracket using previously installed 6x45mm bolt and OEM muffler bolt. Use supplied 6mm nylon lock-nut to secure in place.



7. Install stock gaskets on TBR exhaust header and mount to bike.



8. Install mid-pipe to bike using 57mm barrel clamp and 8x16mm flange bolt and nut.



9. Apply a thin layer of anti-seize and attach TBR slip-tube to muffler using supplied hook springs.



IMPORTANT - PLEASE READ CAREFULLY

We recommend that this performance part be installed by a qualified motorcycle technician. If you have any doubts as to your ability to install this performance part, please consult with your local motorcycle dealer. Read all instructions first before starting installation. Make sure the motorcycle and exhaust system are completely cool before starting the installation. Also, make sure the bike is secure on a centerstand or ideally a service lift during installation. Be sure to save all stock components for possible use later.

Warranty

Two Brothers Racing products are intended for closed course competition purposes only, and therefore are sold "as is" without warranty. Two Brothers Racing specifically disclaims any warranties of merchantability or fitness for a particular purpose and disclaims all responsibility for consequential and incidental damages or any other losses arising from the use of these products or parts.



401 South Grand Ave., Santa Ana, CA 92705
Tel: 714.550.6070 Fax: 714.550.9661 www.twobros.com

**Kawasaki
NINJA 300**

Full Exhaust System
Part # 005-3890105-T


TARMAC




Qty.	Description	Part Number
1	Muffler Canister	Varies
1	Slip-On Tube	005-38901S
1	Header	005-32701H
1	57mm Barrel Clamp	005-27-57MSH
1	58mm Barrel Clamp	005-27-58MSH
1	Bracket	005-327-B
1	6x45mm Socket Head Cap Screw	005-SH645
2	8x16mm Socket Head Cap Screw	005-SH816
1	Flange Nut 6mm	005-FN6
2	Flange Nut 8mm	005-FN8
2	45mm Spring	005-S45
1	Anti-Seize	031-P09175
1	TBR Sticker Kit	015-10212

Installation Instructions

- Slide 58mm barrel clamp on the end of the slip-on tube.



- Install the TBR muffler assembly to the motorcycle and attach using the supplied 8x16mm socket bolt and 8mm flange nut.



- Tighten barrel clamp.



- Re-install lower fairing.



- Double check your work.

- Before you run the bike, clean off all fingerprints and dirt, as any oily residue will etch the metal and become somewhat permanent when the system gets hot. Run the bike and enjoy. It is normal for some white smoke to appear the first time you start the bike. This is packing/manufacturing oil from inside the pipe burning off. Check for gaps or leaks. If you find a leak, a little high temperature silicon sealant should fix it. After 50 to 100 miles, recheck all fasteners for tightness.

Care & Cleaning

Care & Cleaning

Keep system free of dirt and moisture. Store in a cool, dry place. Make sure vehicle is completely cool before maintenance.

Stainless Header System: Polished stainless steel pipes will turn a light golden hue after a few heat cycles, this is a normal characteristic of high quality stainless steel. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Titanium Header System: Polished titanium pipes will experience color shift ranging from deep blue/purple through amber after a few heat cycles. This is a normal characteristic of high quality titanium. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Polished Aluminum Canisters: Use an aluminum or mag wheel polish to restore the bright finish to factory spec.

Brushed Aluminum Canisters: Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Carbon Fiber Canisters: Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve. TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

Titanium Mufflers: For cleaning use a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve. TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

Repack all road canisters at the first signs of packing material deterioration. Part #005-10038
Repack all offroad canisters after every 10 hours of use. Part #005-10038MX

NEVER dyno test your bike with carbon fiber or titanium canisters installed - the intense heat and lack of cooling air can quickly burn through the canister material. Two Brothers Racing does not provide a warranty for burned canisters.