



401 South Grand Ave., Santa Ana, CA 92705  
Tel: 714.550.6070 Fax: 714.550.9661 www.twobros.com

## CAN-AM MAVERICK 1000

V.A.L.E.™ Slip-On Exhaust System with M-2 Exhaust Canister  
Part # 005-3520409DV



### Parts List

Qty.	Description	Part Number
1	Muffer Canister Left	005-352-209ML
1	Muffer Canister Right	005-352-209MR
2	Slip-On Tube Assembly	005-35204S
2	Muffer Clamp	005-27-63MSH
2	X-Ring KIT	005-7-2-3KIT
1	Anti-seize Lubricant	031-P09175

### IMPORTANT - PLEASE READ CAREFULLY

We recommend that this performance part be installed by a qualified motorcycle technician. If you have any doubts as to your ability to install this performance part, please consult with your local motorcycle dealer. Read all instructions first before starting installation. Make sure the motorcycle and exhaust system are completely cool before starting the installation. Also, make sure the bike is secure on a centerstand or ideally a service lift during installation. Be sure to save all stock components for possible use later. This exhaust was not tested with OEM or aftermarket accessories, damage may occur and is not the responsibility of Two Brothers Racing.

#### Care & Cleaning

Keep system free of dirt and moisture. Store in a cool, dry place. For cleaning use a mild spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

**Stainless Header System:** Polished stainless steel pipes will turn a light golden hue after a few heat cycles, this is a normal characteristic of high quality stainless steel.

**Carbon Fiber Mufflers:** Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the Carbon Fiber sleeve. TBR sells repack kits (TBR part # 005-10038) that include new rivets and repack material as well as a drill bit (#30), making it easy to do yourself. Also, NEVER dyno test your bike with carbon fiber mufflers installed - the intense heat and lack of cooling air can quickly cause the CF material to burn. Two Brothers Racing does not provide a warranty for burned carbon fiber.

**Aluminum Mufflers:** Use an aluminum or mag wheel polish such as Mother's to restore the bright finish to factory spec.

Repack all road canisters every 3,000 miles. Part #005-10038

Two Brothers Racing products are intended for closed course competition purposes only, and therefore are sold "as is" without warranty. Two Brothers Racing specifically disclaims any warranties of merchantability or fitness for a particular purpose and disclaims all responsibility for consequential and incidental damages or any other losses arising from the use of these products or parts.

### Installation Instructions

1. Make sure the UTV is completely cool before starting the installation. Make sure the UTV is secure on a level surface and parking brake set.
2. Loosen muffler joint clamps, and remove stock muffler. For ease of installation do one side at a time.
5. Align muffler and tighten the 4 X-Ring bolts.



3. Attach TBR slip tube to TBR muffler using the 2 piece X-Rings and 6x20mm socket head cap screws with lock washer that are provided. Leave loose enough to make some adjustments on the UTV.



4. Attach barrel clamp to end of slip tube and put a small amount of anti-seize to the inside of the TBR slip tube before installation. Install TBR muffler assembly to UTV.



6. Tighten barrel clamp.



7. Repeat on other side.
8. Before you run the UTV, clean off all fingerprints and dirt, as any oily residue will etch the metal and become somewhat permanent when the system gets hot. Run the UTV and enjoy. It is normal for some white smoke to appear the first time you start the UTV. This is packing/manufacturing oil from inside the pipe burning off. Check for gaps or leaks. After 50 to 100 miles, recheck all fasteners for tightness.

