



Part # FE101

Honda CBR600RR 2007-2011

Fender Eliminator Kit Contents

Description	Qty	Description	Qty
1 Pc. bracket	1	6x15mm washer	2
5MM lock nuts	2	6x12mm washer	2
6X12 bolt	2	6mm lock nut	2

Use blue thread lock to secure bolts. Refer to factory owner's manual for proper torque values.

- Remove rider and passenger seats.
- Remove rear Bodywork by removing four bolts under rear seat.
- Disconnect brake and marker light wires.
- Remove rear fender brackets by removing two hex head bolts on each side. (Ref 1 #1) Unclamp wires from wire clamp under left side bracket.
- Remove two nuts holding on the brake light. Pull lens straight out from bracket.
- Remove marker light nuts and take marker lights off bracket.
- Assemble brake light and Vortex Fender Eliminator kit. Tighten with two 6MM nuts. (Ref 2)
- Re-install marker lights to fender brackets and check that they are on the correct side.
- Install and tighten right side fender bracket.
- Loosely install Vortex Fender Eliminator and brake light to right bracket using stock 5MM x 15 bolt and supplied 5MM lock nut. (Ref 1 #2)
- Run wires through left side fender bracket using factory clips. Loosely install left side fender bracket. **Caution: Route wire securely and away from the exhaust pipe.**
- Install Vortex Fender Eliminator on left side bracket with factory wire clip, 5MM bolt and 5MM provided lock nut.
- Tighten Vortex Fender Eliminator and side fender brackets.
- Reconnect lights in reverse order.
- Install rear Bodywork and seats in reverse order.
- Use remaining hardware for mounting license plate.

