



Part # FE121

BMW S1000RR 10-13

Fender Eliminator Kit Contents

Description	Quantity	Description	Quantity
Fender Brackets	1	6x12mm Washer	2
6x15mm Washer	4	6x12 Bolt	4
6mm Locknut	4	5/62x1" Grommet	1
Plastic Washer	1	5x16 Button Head Bolt	1
5x10mm Washer	1		

- Remove rear seat.
- Remove any contents in the storage compartment.
- Loosen and remove stock fender.
- Cut turn signal wiring zip ties (Cut and Label Wires). (Shown Below)
- Remove under tail.
- Remove stock fender spacers from inside the under tail.
- Install VORTEX Fender Eliminator using 2 socket cap 6x1.00x12 bolts, 6mm fender (6x15) washers and 6mm lock nuts. **NOTE: BUTTON HEADS MUST FACE UP (TOWARD RIDER) WITH WASHERS!!!** There is not enough clearance between the sub frame and under tail to use locknuts in this location. (Shown Below)
- Install supplied rubber grommet.
- Install under tail. Once under tail is installed there will be an open hole from the stock fender kit. Take the plastic spacer included in the VORTEX kit; line it up in-between the sub frame and under tail (Shown Below). While holding the spacer in place with your fingers take the 5x16 bolt and washer and screw into the sub frame from beneath the under tail.
- To complete process, feed wiring through rubber grommet. Install and wire turn signals and check for proper function. Install Seat.