

60-0750LB BMW S1000RR Stator Cover Protector

Installation Instructions

- 1) Remove the four bolts from the bottom of the LHS OEM cover.
- 2) Attach the skid plate to the Woodcraft cover by bolting it from the inside.
IMPORTANT - USE THREADLOCKING COMPOUND ON THE THREE SKID PLATE MOUNTING BOLTS
- 3) Install the Woodcraft cover with the included mounting hardware.
- 4) Start the motorcycle and inspect for any leaks before riding.



60-0750LB BMW S1000RR Stator Cover Protector

Installation Instructions

- 1) Remove the four bolts from the bottom of the LHS OEM cover.
- 2) Attach the skid plate to the Woodcraft cover by bolting it from the inside.
IMPORTANT - USE THREADLOCKING COMPOUND ON THE THREE SKID PLATE MOUNTING BOLTS
- 3) Install the Woodcraft cover with the included mounting hardware.
- 4) Start the motorcycle and inspect for any leaks before riding.



60-0750LB BMW S1000RR Stator Cover Protector

Installation Instructions

- 1) Remove the four bolts from the bottom of the LHS OEM cover.
- 2) Attach the skid plate to the Woodcraft cover by bolting it from the inside.
IMPORTANT - USE THREADLOCKING COMPOUND ON THE THREE SKID PLATE MOUNTING BOLTS
- 3) Install the Woodcraft cover with the included mounting hardware.
- 4) Start the motorcycle and inspect for any leaks before riding.

