



**50-0413 Yamaha FZ6
Frame Slider Installation Instructions**

1) Remove your OEM motor mount bolts. The sliders use the engine mounts shown in the picture on the right.

2) Attach the slider bases to the motorcycle using the 10mm bolts provided, threading them in place of your motor mount bolt. Torque to OEM recommended specifications (consult service manual).

3) Slide the plastic slider over the top of the base and secure in place using the 8mm countersunk bolt provided. The bolt passes first through the non threaded hole and then screws into the threaded hole on the far side of the base. The plastic is undersized on the far side of the slider to act as a locknut for the bolt

Woodcraft Technologies, Inc
978-297-2977
www.woodcraft-cfm.com



**50-0413 Yamaha FZ6
Frame Slider Installation Instructions**

1) Remove your OEM motor mount bolts. The sliders use the engine mounts shown in the picture on the right.

2) Attach the slider bases to the motorcycle using the 10mm bolts provided, threading them in place of your motor mount bolt. Torque to OEM recommended specifications (consult service manual).

3) Slide the plastic slider over the top of the base and secure in place using the 8mm countersunk bolt provided. The bolt passes first through the non threaded hole and then screws into the threaded hole on the far side of the base. The plastic is undersized on the far side of the slider to act as a locknut for the bolt

Woodcraft Technologies, Inc
978-297-2977
www.woodcraft-cfm.com

