

Assembly Diagram



No.	ltem	Description	Qty.
1	13141-710-R	Yoshimura RH Midpipe	1
2	13141-710-L	Yoshimura LH Midpipe	1
3	13141-713	Yoshimura Tailpipe	1
4	CRYM5127R	Yoshimura Muffler Assembly	1
5	MCYM5-GCBX	Muffler Clamp	1
6	HT SHLDR77	Muffler Clamp Heat Insulator	1
7	13141-RMBKT	Muffler Bracket Adapter	1
8	M8X16	8mm x 16mm Socket Head Cap Screw	1
9	M8X40	8mm x 40mm Socket Head Cap Screw	1
10	M8ALCSW-00	8mm Aluminum Counter Sink Washer	1
11	8MMNUT	8mm Flange Nut	2
12	27-64MSH	Exhaust Clamp	2
13	RACE-SPS-1	Medium Exhaust Spring	2
14	RACE-SPX-1	Short Exhaust Spring	2
**	M18X13PLG	O2 Bung Plug	1
**	ST-200	Spring Puller	1
**	17029	Sticker Sheet	1

** Not shown on diagram.

Removal

- 1. Remove the muffler and header heatshields.
- 2. Remove the muffler exhaust clamp.
- 3. While securely supporting the stock muffler, remove the muffler mount bolt and carefully remove the stock muffler assembly.
- 4. Remove the two O2 sensors from the pre-muffler chamber assembly.
- 5. Disconnect and remove exhaust valve cables from the pre-muffler chamber assembly.
 - Note¹: Exhaust valve cables will not be used with the Yoshimura 3/4 system. Remove exhaust valve cables from servo motor.
 - Note²: Do not disconnect servo motor connector.
- 6. Remove the three chassis mount bolts securing pre-muffler chamber assembly to frame.
- 7. While securely supporting the pre-muffler chamber assembly, loosen the two exhaust clamps between the header and carefully remove pre-muffler chamber assembly.

Note: The stock exhaust gaskets will not be used with the Yoshimura 3/4 system.

Installation

 Remove the lower muffler mount bracket bolt from right footpeg bracket. Install (No. 7) 13141-RMBKT, muffler bracket adapter on the backside of the muffler mount bracket using the provided (No. 8) M8X16, bolt.



2. Align (No. 7) *13141-RMBKT*, muffler bracket adapter to the backside of the right footpeg bracket. Secure using the stock bolt.



- 3. Install (No. 12) 27-64*MSH,* exhaust clamp onto (No. 1,2) *13141-710-L/R,* left and right tailpipe inlets. Do not torque at this time.
- 4. Install (No. 1,2) *13141-710-L/R,* left and right right midpipe onto header outlet and align chassis mount bracket to chassis.
 - Note: Installing the left and right midpipe simultaneously by interlocking both chassis mount brackets may ease installation.



- 5. Secure left and right midpipe to chassis using the stock bolt, washer and provided (No.11) *8MMNUT,* nut as shown on the assembly diagram. Do not torque at this time.
- 6. Install (No. 3) *13141-713,* tailpipe onto (No. 1,2) *13141-710-L/R,* midpipe outlet.

7. Install (No. 6) HT SHLDR77, muffler clamp heat insulator onto (No. 5) MCYM5-GCBX.



- Install (No. 4) *CRYM5127R*, muffler over tailpipe outlet. Slide (No. 5) *MCYM5-GCBX*, muffler clamp over muffler and secure to the backside of the stock muffler mount bracket using the provided (No. 9) *M8X40*, bolt, (No. 10) *M8ALCSW-00*, counter sink washer, and (No. 11) *8MMNUT*, nut. See diagram for proper orientation and order of hardware. Torque (No.9) *M8X40*, bolt to 21.6 Nm (2.1 kg-m, 16 ft-lb).
- 9. Install (No. 14) *RACE-SPX-1*, short spring with insulator between the muffler and tailpipe.
- 10. Install (No. 13) *RACE-SPS-1*, medium spring between midpipe and tailpipe.
- 11. Torque the stock chassis mount bolt to factory specification.
- 12. Install the stock O2 sensors into (No. 1,2) 13141-710-L/R, left and right midpipe.
- 13. Torque (No. 12) *27-64MSH,* exhaust clamp to 8.5 Nm (0.86 kg-m, 6 ft-lb).
- 14. Before starting vehicle, check for proper clearance between new exhaust system and rear suspension (i.e. tire, swingarm, brakes, rear shock, and etc.)If any problem is found, please carefully follow through the installation steps again. If problem still persists, please call Yoshimura Tech Department at (800) 634-9166 / in CA (909) 628-4722.
- 15. It is recommended that the muffler and tailpipe be wiped down with rubbing alcohol to remove oil and fingerprints. This will help prevent tarnishing of the finish after the exhaust is heated up.