

RESEARCH&DEVELOPMENT OF AMERICA, INC.


 $5420 \; \text{DANIELS STREET STE A, CHINO CALIF. } 91710 \cdot (800) \\ 634-9166 \cdot (909) \\ 628-4722 \cdot \text{FACSIMILE } (909) \\ 591-2198 \cdot (909) \\ 628-4722 \cdot$ 

www.yoshimura-rd.com

## CHASSIS PROTECTOR SET

**SUZUKI** GSX-R600/750

040HA116000



## Parts List:

NO.	DESCRIPTION	QTY	PART #
1	10mm x 120mm Bolt	1	M10X120
2	10mm x 100mm Bolt	1	M10X100
3	Aluminum Insert for Chassis Protector	2	040HA-MMI-10
4	Yoshimura Chassis Protector	2	1115-A05-01
5	Aluminum Spacer (Right Side)	1	040HA116000SR
6	Aluminum Spacer (Left Side)	1	040HA116000SL
**	Yoshimura Sticker	2	17020C

Caution: Motorcycle can be extremely hot after riding. Let motorcycle cool down before beginning installation. Always wear hand and eye protection and take precautionary measures to avoid injury.

Note: Read through all instructions before beginning installation.

## Tools Needed:

Ratchet and Extension Metric Allen Socket Set Torque Wrench Rotary Tool (Dremel)

## Installation Steps:

- 1. Cut out supplied cutting templates.
- 2. Cut out bolt recess holes on template.
- 3. Using a pen or a sharp object, punch out the center of the crosshair on the template for the chassis mount location.
- 4. Align template to fairing and bolt recess hole; Tape to fairing using masking tape. (Note: Masking tape is recommended. Other tape may leave residue when removing.)
- 5. Using a marker, mark the center of the hole location where punched earlier. Be sure the mark is visible on fairing.
- 6. Carefully remove the template from the fairing. (Note: Template will be re-taped. Be sure not to tear, wrinkle or damage template.)
- 7. Drill a pilot hole where previously marked. Check that it is centered to the engine mount bolt.
- 8. Cut out the chassis protector location hole on template.
- 9. Re-align and re-tape template to fairing and trace around the chassis protector location hole using a marker.
- 10. Remove template and carefully begin to open up the pilot hole using a rotary tool. Periodically check fit spacer during this process. (Note: Widen hole just enough so spacer and derlin slider clears fairing. Removal of fairing may ease installation. If removal of fairing is desired, remove as per Factory Service Manual.)
- 11. Repeat steps for opposite side.
- 12. Install chassis protectors. See diagram for orientation.
- 13. Torque bolts to factory specifications.

IMPORTANT NOTE: Install Yoshimura Chassis Protector one side at a time. Removing both engine mount bolts simultaneously may cause engine to sag or drop causing the mounting holes to be misaligned.







Fig. 2

