

# Armor Rim Strip Tape, 11-0061 & 11-0062



## **Step 1**

CLEAN YOUR RIM (do not use WD-40 or other like products that leave an oily residue as this will prevent the tape from sticking correctly)

## **Step 2**

Peel paper backing off the tape just past the hole on the short end.

## **Step 3**

Align the hole in the tape with the Schrader valve hole on the rim, and press down the exposed adhesive section of the tape.

## **Step 4**

Continue by simultaneously pulling off the paper backing and firmly seating the rim tape over the spoke nipples in the center of the rim until the two ends overlap.

## **Step 5**

Cut the hole for the rim lock with a hobby knife once the tape has been fully installed.

USE CAUTION WITH THE HOBBY KNIFE TO AVOID INJURING YOURSELF.

