





## SUPPLEMENTARY MANUAL

for BLP-UO1

REMOVE THE SEAT. REMOVE THE TWO BOLTS OF THE REAR LIGHT ASSEMBLY.



CUT THE RED/WHITE WIRE.

CONNECT THE BLP RED WIRE TO RED/WHITE WIRE OF REAR LIGHT, WHICH IS AT THE WIRING HARNESS SIDE.

CONNECT THE BLP GREEN WIRE TO RED/WHITE WIRE OF REAR LIGHT, WHICH IS AT THE REAR LIGHT SIDE.

CONNECT THE BLP BLACK WIRE TO BLACK WIRE OF REAR LIGHT.



TYPICAL POSITION FOR BRAKE LIGHT PRO.