

SUPPLEMENTARY MANUAL

for BLP-UO1

REMOVE THE PASSENGER SEAT.



REMOVE THE MAIN SEAT.




REMOVE THE UPPER SEAT COVER.





LOCATE THE REAR LIGHT CONNECTOR BELOW UPPER SEAT COVER AT RIGHT SIDE.

(BLACK, 3-POLE CONNECTOR)



CUT THE BLUE/RED WIRE.
CONNECT THE BLP RED WIRE TO
BLUE/RED WIRE END, WHICH IS AT
THE WIRING HARNESS SIDE.




CONNECT THE BLP GREEN WIRE TO BLUE/RED WIRE END, WHICH GOES TO THE REAR LIGHT CONNECTOR.

CONNECT THE BLP BLACK WIRE TO BLACK/WHITE WIRE.





CONNECT THE BLP BLACK WIRE TO BLACK/YELLOW WIRE.



TYPICAL POSITION FOR BRAKE LIGHT PRO.

