## SUPPLEMENTARY MANUAL

for BLP-UO1

REMOVE THE PASSENGER SEAT.




LOCATE THE REAR LIGHT CONNECTOR UNDER PASSENGER SEAT NEAR REAR LIGHT.

(BLACK, 3-POLE CONNECTOR)



CUT THE BLUE/RED WIRE.
CONNECT THE BLP RED WIRE TO
BLUE/RED WIRE END, WHICH IS AT
THE WIRING HARNESS SIDE.
CONNECT THE BLP GREEN WIRE TO
BLUE/RED WIRE END, WHICH GOES
TO THE REAR LIGHT CONNECTOR.
CONNECT THE BLP BLACK WIRE TO
BLACK/YELLOW WIRE.









TYPICAL POSITION FOR BRAKE LIGHT PRO.

