

**PART#: DBNC- BLEED NIPPLE CAP
INSTALLATION INSTRUCTIONS**



DRIVEN PERFORMANCE PRODUCTS
WWW.DRIVENRACING.COM
866-5-DRIVEN

1. Remove stock gasket off bleed nipple.
2. Install bleed nipple gasket into bleed nipple cap. (make sure gasket lip is under cap lip)
3. Push and twist bleed nipple cap onto bleed nipple.(make sure it doesn't come off easily)



THIS PRODUCT TO BE INSTALLED BY A CERTIFIED TECH*

NOT INTENDED AS OEM REPLACEMENT

**PART#: DBNC- BLEED NIPPLE CAP
INSTALLATION INSTRUCTIONS**



DRIVEN PERFORMANCE PRODUCTS
WWW.DRIVENRACING.COM
866-5-DRIVEN

1. Remove stock gasket off bleed nipple.
2. Install bleed nipple gasket into bleed nipple cap. (make sure gasket lip is under cap lip)
3. Push and twist bleed nipple cap onto bleed nipple.(make sure it doesn't come off easily)



THIS PRODUCT TO BE INSTALLED BY A CERTIFIED TECH*

NOT INTENDED AS OEM REPLACEMENT