




## SUPPLEMENTARY MANUAL

for ESE-K01

REMOVE THE PASSENGER SEAT.



REMOVE THE MAIN SEAT.



UNPLUG THE  
EXHAUST SERVO-MOTOR  
CONNECTORS.

(WHITE, 3-POLE TRIANGULAR AND TRANSPARENT, 2-  
POLE CONNECTORS BELOW MAIN SEAT)



# Kawasaki Z1000SX


2011-2013



**REMOVE THE EXHAUST SERVO-MOTOR.**  
(BELOW MAIN SEAT)



**PLUG ESE CONNECTORS TO EXHAUST SERVO-MOTOR CONNECTORS.**



**TYPICAL POSITION FOR EXHAUST SERVO ELIMINATOR.**

