

## CARE AND CLEANING

The best way to keep your American Kargo bag looking fresh and clean is with water. That's right, your AK bag requires almost no maintenance, other than periodic cleaning with water. If you discovered a way to get your bag so dirty that water alone isn't going to cut it, you can scrub the bag with a soft brush, mild soap and water to remove any dirt or

residue. We do not recommend the use of harsh solvents or chemicals to clean your bag as they can break down the materials in your bag and leave it faded. Once your bag is clean don't be tempted to place it in a dryer. Dryers can damage the protective coatings on your bag so we recommend that you hang it up to air dry.





## WARRANTY

American Kargo provides lifetime warranty coverage for its luggage and accessory products to the items' original retail purchaser. The Lifetime Limited Warranty covers defects in materials, design or workmanship.

American Kargo will repair or replace, at their option, items that are defective. The purchaser is required to obtain advance return authorization and for shipping the affected item to American Kargo for warranty repair or replacement. Damage caused by improper use or improper installation is not a defect; therefore repair or replacement of a damaged product will not be covered under this warranty.

This warranty has other provisions and conditions, so please review the coverage and return authorization information at www.americankargo.com for additional information. If you have any comments, or are not satisfied with the performance of your American Kargo accessory, please call us at (310) 761-8151.

