

## SUPPLEMENTARY MANUAL

for GPDS-HO1

REMOVE THE MAIN AND PASSENGER SEATS.
REMOVE THE LEFT AND RIGHT BLACK FRAME COVERS
BELOW THE MAIN SEAT AND FUEL TANK.



REMOVE THE
METAL CONNECTOR HOLDER
ABOVE AIRBOX AT THE RIGHT SIDE.



CONNECT DS-SERIES CONNECTOR

DIAGNOSTIC SYSTEM CONNECTOR.

(RED, 4-POLE CONNECTOR WITH RED CAP
UNDER BLACK AND WHITE CONNECTORS
AT THE RIGHT SIDE)







TYPICAL POSITION FOR THE GEAR INDICATOR.

