

SUPPLEMENTARY MANUAL

for GPDS-K01

REMOVE THE MAIN SEAT. LIFT UP OR REMOVE THE FUEL TANK.



CONNECT DS-SERIES CONNECTOR TO

DIAGNOSTIC SYSTEM CONNECTOR.

(BLACK, 4-POLE KDS CONNECTOR WITH DUMMY PLUG (WITHOUT WIRES)
AT RIGHT SIDE BELOW SEAT NEXT TO FRAME)



TYPICAL POSITION FOR THE GEAR INDICATOR.

