



SUPPLEMENTARY MANUAL

for GPDS-K01

REMOVE THE SEAT.
LIFT UP OR REMOVE THE
FUEL TANK.



CONNECT DS-SERIES CONNECTOR
TO
DIAGNOSTIC SYSTEM CONNECTOR.
(BLACK, 4-POLE KDS CONNECTOR WITH
BLACK CAP ON RIGHT SIDE NEAR FRAME)



TYPICAL POSITION FOR THE
GEAR INDICATOR.

