





SUPPLEMENTARY MANUAL

for GPDS-K04

REMOVE THE MAIN AND PASSENGER SEATS.
LIFT UP OR REMOVE THE FUEL TANK.



CONNECT DS-SERIES CONNECTOR TO
DIAGNOSTIC SYSTEM CONNECTOR.
(WHITE, 4-POLE KDS CONNECTOR WITH
WHITE CAP UNDER SEAT)



TYPICAL POSITION FOR THE
GEAR INDICATOR.

