

Yamaha FZ6 Fazer

2004-2008



SUPPLEMENTARY MANUAL

for GPX-Y01

REMOVE THE MAIN SEAT.



LIFT UP OR REMOVE THE
FUEL TANK.



PLUG GPX CONNECTORS IN-LINE
WITH THE SPEED SENSOR
CONNECTORS.

(WHITE, 3-POLE TRIANGULAR CONNECTORS
IN DUST BOOT BELOW THE FUEL TANK)



Yamaha FZ6 Fazer

2004-2008



**CONNECT GPX BLACK/GREEN WIRE
TO
GRAY WIRE OF
CRANKSHAFT POSITION SENSOR
CONNECTOR.
(BLACK, 2-POLE CONNECTOR
AT RIGHT SIDE BELOW FUEL TANK)**



**CONNECT GPX RED WIRE TO
BROWN WIRE OF REAR BRAKELIGHT
SWITCH CONNECTOR.
(BROWN, 2-POLE CONNECTOR
BELOW FUEL TANK)**



**TYPICAL POSITION FOR THE
GEAR INDICATOR.**

