

SUPPLEMENTARY MANUAL

for QSE-1 + QSH-F4B

REMOVE THE PASSENGER SEAT.

REMOVE THE MAIN SEAT.



LIFT UP OR REMOVE THE FUEL TANK.



PLUG QSH CONNECTORS IN-LINE
WITH THE FUEL INJECTOR
CONNECTORS.

(GRAY, 2-POLE CONNECTORS BELOW AIRBOX)





CONNECT QSH BLACK WIRE TERMINAL TO CHASSIS GROUND.



MOUNT THE QSE SENSOR.

(Use the New Bolt and Washers Supplied With the Unit. Make sure to place one Washer above the sensor and one Washer below the sensor. Tighten the screw by 3-4 Nm.

WHEN TIGHTENED, DO NOT TRY TO ROTATE THE SENSOR BODY.)



Typical position for the QuickShifter easy.

