

SUPPLEMENTARY MANUAL

for QSE-1 + QSX-P4B

REMOVE THE SIDE COVERS FROM FUEL TANK.



REMOVE THE MAIN AND PASSANGER SEAT.



REMOVE THE FUEL TANK.





REMOVE THE AIRBOX.




PLUG QSX CONNECTORS IN-LINE WITH THE IGNITION COIL CONNECTORS.

(BLACK, Z-POLE CONNECTORS BELOW AIRBOX)



MOUNT THE QSX MODULE TO THE INNER SIDE OF THE FRAME BY THE SUPPLIED VELCRO STRIPS, AND SECURE THE CABLES WITH CABLE TIES.

(AVOID DIRECT CONTACT WITH HEAT SOURCES, LIKE THE CYLINDER HEAD.)




CONNECT QSX BLACK WIRE TERMINAL TO CHASSIS GROUND.



MOUNT THE QSE SENSOR.

(Use the New Bolt and Washers Supplied With the Unit. Make sure to place one Washer above the sensor and one Washer below the sensor. Tighten the screw by 3-4 Nm.

WHEN TIGHTENED, DO NOT TRY TO ROTATE THE SENSOR BODY.)



TYPICAL POSITION FOR THE QUICKSHIFTER EASY.

