

SUPPLEMENTARY MANUAL

for QSE-1 + QSX-P4B

REMOVE THE SEATS.
REMOVE THE REAR FAIRING
FROM LEFT SIDE.



REMOVE THE FUEL TANK.



REMOVE THE AIRBOX.





PLUG QSX CONNECTORS IN-LINE WITH THE IGNITION COIL CONNECTORS.

(BLACK, Z-POLE CONNECTORS BELOW AIRBOX)



MOUNT THE QSX MODULE TO THE INNER SIDE OF THE FRAME WITH THE SUPPLIED VELCED STRIPS, AND SECURE THE CABLES WITH CABLE TIES.

(AVOID DIRECT CONTACT WITH HEAT SOURCES, LIKE THE CYLINDER HEAD.)



CONNECT QSX BLACK WIRE





MOUNT THE QSE SENSOR.

(PLACE THE CONICAL WASHERS SUPPLIED AT THE TWO SIDES OF THE SENSOR LIKE THIS: (O).

TIGHTEN THE LOCKNUT TO THE WASHER BY HAND FULLY AND THEN BY 1/4 TURN USING A WRENCH.

FOR DIFFERENT MOUNTING OPTIONS, REFER TO THE SENSOR INSTALL GUIDE.)



TYPICAL POSITION FOR THE QUICKSHIFTER EASY.

