

MV Agusta Brutale 1078RR

2008-2012




SUPPLEMENTARY MANUAL

for SH-D01

REMOVE THE SEAT.
REMOVE BLACK FRAME COVER
AT LEFT SIDE BELOW FUEL TANK.



PLUG SPEEDOHEALER CONNECTORS
IN-LINE WITH THE VEHICLE SPEED
SENSOR (VSS) CONNECTORS.
(BLACK, 3-POLE CONNECTORS
AT LEFT SIDE NEXT TO STAND SWITCH)



TYPICAL POSITION
FOR SPEEDOHEALER.

