

SUPPLEMENTARY MANUAL

for SH-HO2

REMOVE THE SEAT.



REMOVE BLACK COVER AT RIGHT SIDE BELOW FUEL TANK.



REMOVE INTAKE FROM AIRBOX.





PLUG SPEEDOHEALER CONNECTORS IN-LINE WITH THE VEHICLE SPEED SENSOR (VSS) CONNECTORS.

(SEMI-TRANSPARENT, 3-POLE CONNECTORS
AT RIGHT SIDE BELOW AIRBOX)



TYPICAL POSITION FOR REMOTE BUTTON.



TYPICAL POSITION FOR SPEEDOHEALER.

