

## SUPPLEMENTARY MANUAL

for SH-KO1

REMOVE THE PASSENGER AND MAIN SEATS.



REMOVE THE LEFT AND RIGHT FRAME COVERS BELOW FUEL TANK.

LIFT UP OR REMOVE THE FUEL TANK.



PLUG SPEEDOHEALER CONNECTORS
IN-LINE WITH THE VEHICLE SPEED
SENSOR (VSS) CONNECTORS.

(BLACK, 3-POLE CONNECTORS AT LEFT SIDE BELOW FUEL TANK)







TYPICAL POSITION FOR SPEEDOHEALER.

