



RESEARCH&DEVELOPMENT OF AMERICA, INC.

5420 DANIELS STREET STE A, CHINO CALIF. 91710 · (800) 634-9166 · (909) 628-4722 · FAX (909) 591-2198

www.yoshimura-rd.com

Butt Connector Installation:

1. Strip wire ends 1/4" - 1/2" and insert into *BN-SSS-22-18*, butt connectors.
2. Center the spliced wire ends in the middle and using a heatgun or lighter, apply heat evenly on the outer edges of the butt connector to shrink and hold wires in place.
3. Making sure that the stripped ends are centered, heat the center of the butt connector evenly until the solder begins to liquify.
4. Allow to cool completely and tug both ends of the wires to verify that connection is secured.

Scan for link to butt connector instruction video.



RESEARCH&DEVELOPMENT OF AMERICA, INC.

5420 DANIELS STREET STE A, CHINO CALIF. 91710 · (800) 634-9166 · (909) 628-4722 · FAX (909) 591-2198

www.yoshimura-rd.com

Butt Connector Installation:

1. Strip wire ends 1/4" - 1/2" and insert into *BN-SSS-22-18*, butt connectors.
2. Center the spliced wire ends in the middle and using a heatgun or lighter, apply heat evenly on the outer edges of the butt connector to shrink and hold wires in place.
3. Making sure that the stripped ends are centered, heat the center of the butt connector evenly until the solder begins to liquify.
4. Allow to cool completely and tug both ends of the wires to verify that connection is secured.

Scan for link to butt connector instruction video.



RESEARCH&DEVELOPMENT OF AMERICA, INC.

5420 DANIELS STREET STE A, CHINO CALIF. 91710 · (800) 634-9166 · (909) 628-4722 · FAX (909) 591-2198

www.yoshimura-rd.com

Butt Connector Installation:

1. Strip wire ends 1/4" - 1/2" and insert into *BN-SSS-22-18*, butt connectors.
2. Center the spliced wire ends in the middle and using a heatgun or lighter, apply heat evenly on the outer edges of the butt connector to shrink and hold wires in place.
3. Making sure that the stripped ends are centered, heat the center of the butt connector evenly until the solder begins to liquify.
4. Allow to cool completely and tug both ends of the wires to verify that connection is secured.

Scan for link to butt connector instruction video.



RESEARCH&DEVELOPMENT OF AMERICA, INC.

5420 DANIELS STREET STE A, CHINO CALIF. 91710 · (800) 634-9166 · (909) 628-4722 · FAX (909) 591-2198

www.yoshimura-rd.com


Butt Connector Installation:

1. Strip wire ends 1/4" - 1/2" and insert into *BN-SSS-22-18*, butt connectors.
2. Center the spliced wire ends in the middle and using a heatgun or lighter, apply heat evenly on the outer edges of the butt connector to shrink and hold wires in place.
3. Making sure that the stripped ends are centered, heat the center of the butt connector evenly until the solder begins to liquify.
4. Allow to cool completely and tug both ends of the wires to verify that connection is secured.

Scan for link to butt connector instruction video.




1. Remove the stock turn signals.
2. In order to reuse the stock turn signal connector, cut the stock turn signal wires as close to the bulb as possible.
3. Strip wire ends $\frac{1}{4}'' - \frac{1}{2}''$.



4. Reconnect turn signal connector and test to determine positive (+) and negative (-) wires on the stock turn signal wires.

5. Install supplied butt connectors following instructions on reverse side of sheet.

6. Re-install and re-connect turn signal and check for proper function.



1. Remove the stock turn signals.


2. In order to reuse the stock turn signal connector, cut the stock turn signal wires as close to the bulb as possible.

3. Strip wire ends $\frac{1}{4}'' - \frac{1}{2}''$.

4. Reconnect turn signal connector and test to determine positive (+) and negative (-) wires on the stock turn signal wires.

5. Install supplied butt connectors following instructions on reverse side of sheet.

6. Re-install and re-connect turn signal and check for proper function.




1. Remove the stock turn signals.
2. In order to reuse the stock turn signal connector, cut the stock turn signal wires as close to the bulb as possible.
3. Strip wire ends $\frac{1}{4}'' - \frac{1}{2}''$.



4. Reconnect turn signal connector and test to determine positive (+) and negative (-) wires on the stock turn signal wires.

5. Install supplied butt connectors following instructions on reverse side of sheet.

6. Re-install and re-connect turn signal and check for proper function.



1. Remove the stock turn signals.

2. In order to reuse the stock turn signal connector, cut the stock turn signal wires as close to the bulb as possible.

3. Strip wire ends $\frac{1}{4}'' - \frac{1}{2}''$.

4. Reconnect turn signal connector and test to determine positive (+) and negative (-) wires on the stock turn signal wires.

5. Install supplied butt connectors following instructions on reverse side of sheet.

6. Re-install and re-connect turn signal and check for proper function.

