## FOR OFF ROAD/RACE USE ONLY!



Driven TT Rearsets for 2016 Kawasaki ZX-10R Part#: DRP-723

INSTALLATION INSTRUCTIONS

#### Removal

#### **Shifter Side**

- 1. Remove OEM shift rod from bike.
- 2. Remove frame plate from bike.

#### **Brake Side**

- 1. Remove 2 m8 bolts holding heal guard.
- 2. Remove master cylinder plunger pin and retain split pin.
- 3. Remove 2 m8 bolts and remove frame bracket.
- 4. Remove rear brake switch and disconnect it from bike.

### **TOOLS REQUIRED**

- 8mm Open End Wrench
- 5mm Hex Key
- 6mm Hex Key
- 8mm Hex Key
- Needle Nose Pliers
- Screw Driver
- Blue Loctite
- Impact Gun

## THE USE OF BLUE LOCTITE IS REQUIRED ON ALL MOUNTING HARDWARE!

#### Installation

NOTE: ALL PIVOT POINTS MUST BE TIGHTENED USING BLUE LOCTITE AND AN IMPACT GUN.

#### **Shifter Side**

- 1. Install foot peg in frame bracket.
- 2. Install shift rod.
- 3. Install frame bracket onto bike.
- 4. Adjust shift pedal with shift rod and tighten both safety nuts.

## \*For gp shift an ECU re flash will be required(if used with Kawasaki stock QS)


#### **Brake Side**

- 1. Install foot peg in frame bracket.
- 2. Connect master cylinder plunger to brake lever using OEM cotter and pin.
- 3. Install frame bracket to bike.
- 4. Install master cylinder using 2 m8 bolts supplied.
- 5. Use blue Loctite on all bolts and torque all to required setting.
- 6. Make sure nothing interferes with proper operation of motorcycle.

### **TORQUE VALUES**

- M5 = 6FT/LBS
- M6 = 10FT/LBS
- M8 = 25FT/LBS
- M10 = 45FT/LBS


Make final adjustments as necessary and re-check all hardware after the first 500 miles of use.






# FOR OFF ROAD/RACE USE ONLY!







**STANDARD SHIFT** 

**REVERSE SHIFT** 

## FOR OFF ROAD/RACE USE ONLY!



