

Install Guide for **GPX-H02** Harness Kit

For use with the following HONDA motorcycles:

CBF500 (2004-2008), **CBR250R** (2011),
NRX1800 (2004-2006), **Valkyrie Rune** (2004-2006),
VT750 Shadow (2008-2010),
VTX1300 (2003-2011), **VTX1800** (2002-2004)

Disclaimer: Do not attempt to install the product if you don't have basic mechanical skills. HealTech Electronics Ltd. and its distributors shall not be liable for any loss or damage caused by improper installation. If in doubt, please consult with your dealer.

1. Locate the **Speed Sensor coupler**. It is a 3-pole, natural color connector.
 - **CBF500:**
Behind left side cover, in dust boot
 - **CBR250R:**
Behind left side cover
 - **NRX1800, Valkyrie Rune:**
Under seat and fuel tank at the right side, near ECM
 - **VT750:**
Under rider's seat in front left, in dust boot
 - **VTX1300, VTX1800:**
Behind left side cover, under key switch, in dust boot

Confirmation:

Separate the Speed Sensor coupler (you might need to use a small flathead screwdriver to get the coupler apart). Rotate the rear wheel while ignition is on. The speedometer should indicate 0. If so, turn the ignition off and proceed to the next step. Otherwise, if the speedometer registers a speed other than 0, you have not disconnected the correct coupler and need to look again.

2. After separating the Speed Sensor coupler, **plug in** both the male and female 3-pole GIpro harness connectors. Make sure the connectors are fully seated.
*If you have a **SpeedoHealer** installed, you have to connect the plugs in-line in the following order:*

Speed sensor male plug → GIpro → SH → bike female plug

3. Find the RPM signal wire:

CBF500, CBR250R	Yellow/Green <i>(Solid Yellow wire with thin Green stripe)</i> Tachometer signal wire, find either at the ECU connector or at the dashboard connector.
VTX1800, VT750, NRX1800, Valkyrie Rune	Yellow <i>(Solid Yellow)</i> Crankshaft signal wire, find either at the ECU connector or at the 2-pole plug of the ignition pulse generator (pickup coil).
VTX1300	White/Blue <i>(Solid White wire with thin Blue stripe)</i> Crankshaft signal wire, find either at the ECU connector or at the 2-pole plug of the ignition pulse generator (pickup coil).

4. Peel off the black sleeve (tape), leaving about 3 cm (1.2") of this wire exposed.

5. Connect the GIpro **Black/Green** wire to this wire, using the **Red wire tap** connector supplied.

Usage: Place the unstripped run wire (shown in the table above) inside the run channel. Close the side cover until latched. Cut off the excess length, then insert the unstripped tap wire (Black/Green) completely and check its position. Insert the blade (u-contact) and press down by finger pressure. Then, fully depress the u-contact with pliers. Close the hinged top cover until latched.

6. Connect the 4-pole GIpro harness connector to the GIpro display connector.

7. Check whether everything is installed and working properly:

- **Select Neutral and turn ignition On** →

The GIpro display should count from **6** to **1**, then "L" flashes slowly.
(If not, the display is not receiving power and/or ground. Check the connections at the speed sensor connector.)

- **Rotate the wheels** → the display should indicate a rolling wheel.

(If not, the display is not receiving the speed signal. Check the connection at the speed sensor connector.)

- **Start the engine** → "L" should flash **faster** for a few seconds.

(If not, the display is not receiving the RPM signal. Check the wire tap.)

Turn the ignition Off. If the tests still fail, disconnect the 3-pole and 4-pole connectors and check whether the connector pins are bent or pushed out of position. Spray some WD40 into the plugs.

8. Peel off the green plastic from the back of the unit, and mount the display.

9. Neatly route the GIpro harness from the 3-pole plugs to the mounting location, preferably along the frame.

Do not bend the harness near the 4-pole connectors.

Do not route the harness very close to the exhaust pipe or cylinder head.

10. Use black tape to secure and isolate the 4-pole connectors. To minimize cable stress, use the supplied cable ties to fasten the unit and harness to other cables.