

WOODCRAFT


IN50-0339

2 Piece Frame Slider Installation Instructions


- 1) Remove your OEM motor mount bolts. The sliders use the mounting locations shown in the photos at the right.
- 2) With your bodywork in place, fit the bolt and aluminum base on each side of the bike by hand so that you can trace a circle to mark where you need to cut at least a 2" hole for the sliders.

Suggestions: We suggest a 2 inch hole saw with a pilot drill for this job. Most mechanics will first drill a small pilot hole and make sure that the hole is centered over the motor mount hole. You may use an undersized (1 1/2") hole saw and then open the hole up larger with a drum sanding bit in a dremel tool.

- 3) Attach the slider bases to the motorcycle using the 12mm bolts provided, threading them in place of your motor mount bolt. Torque to OEM recommended specifications (consult service manual).
- 4) Slide the plastic slider over the top of the base and secure in place using the 6mm countersunk bolt provided. The bolt passes first through the non threaded hole and then screws into the threaded hole on the far side of the base. The plastic is undersized on the far side of the slider to act as a locknut.



Left Mount



Right Mount



Slider Installed

WOODCRAFT


IN50-0339

2 Piece Frame Slider Installation Instructions

- 1) Remove your OEM motor mount bolts. The sliders use the mounting locations shown in the photos at the right.
- 2) With your bodywork in place, fit the bolt and aluminum base on each side of the bike by hand so that you can trace a circle to mark where you need to cut at least a 2" hole for the sliders.

Suggestions: We suggest a 2 inch hole saw with a pilot drill for this job. Most mechanics will first drill a small pilot hole and make sure that the hole is centered over the motor mount hole. You may use an undersized (1 1/2") hole saw and then open the hole up larger with a drum sanding bit in a dremel tool.

- 3) Attach the slider bases to the motorcycle using the 12mm bolts provided, threading them in place of your motor mount bolt. Torque to OEM recommended specifications (consult service manual).
- 4) Slide the plastic slider over the top of the base and secure in place using the 6mm countersunk bolt provided. The bolt passes first through the non threaded hole and then screws into the threaded hole on the far side of the base. The plastic is undersized on the far side of the slider to act as a locknut.



Left Mount



Right Mount



Slider Installed