



**50-0500 Triumph 675
2 Piece Frame Slider
Installation Instructions**

- 1) Remove your OEM motor mount bolts. The sliders use the most forward engine mount if there are multiple mounts on your motorcycle.
- 2) If needed, with your bodywork in place, fit the bolt and aluminum base on each side of the bike by hand so that you can trace a circle to mark where you need to cut at least a 2" hole for the sliders.
- 3) Attach the slider bases to the motorcycle using the 10 or 12mm bolts provided, threading them in place of your motor mount bolt. Torque to OEM recommended specifications (consult service manual).
- 4) Slide the plastic slider over the top of the base and secure in place using the 8mm countersunk bolt provided. The bolt passes first through the non threaded hole and then screws into the threaded hole on the far side of the base. The plastic is undersized on the far side of the slider to act as a locknut for the bolt
- 5) Cut holes in the bodywork if needed and mount bodywork. The sliders should protrude 1-1.5" from the bodywork.



Left Side Installed



Right Side Installed

Important: The longer base goes on the left side with either bolt



**50-0500 Triumph 675
2 Piece Frame Slider
Installation Instructions**

- 1) Remove your OEM motor mount bolts. The sliders use the most forward engine mount if there are multiple mounts on your motorcycle.
- 2) If needed, with your bodywork in place, fit the bolt and aluminum base on each side of the bike by hand so that you can trace a circle to mark where you need to cut at least a 2" hole for the sliders.
- 3) Attach the slider bases to the motorcycle using the 10 or 12mm bolts provided, threading them in place of your motor mount bolt. Torque to OEM recommended specifications (consult service manual).
- 4) Slide the plastic slider over the top of the base and secure in place using the 8mm countersunk bolt provided. The bolt passes first through the non threaded hole and then screws into the threaded hole on the far side of the base. The plastic is undersized on the far side of the slider to act as a locknut for the bolt
- 5) Cut holes in the bodywork if needed and mount bodywork. The sliders should protrude 1-1.5" from the bodywork.



Left Side Installed



Right Side Installed

Important: The longer base goes on the left side with either bolt